



SUPPLYING DEMAND®

GPSDC97-14486A

GPSDC97-14486A

DRYER HEATING ELEMENT COMPLETE CANISTER

COMPATIBLE MODELS:

40289032010 40289032011 40289032012 DV203AES DV203AESXAC DV203AEW DV203AEW/XAA-0000 DV203AEWXAA DV203AEWXAC DV206AES DV206AES/XAA-0000 DV206AESXAA DV206AESXAC DV206LEW DV206LEWXAC DV209AEW DV209AEW/XAA-0000 DV209AEWXAA DV210AES DV210AESXAC DV210AEW DV210AEW/XAA DV210AEWXAC DV218AEB DV218AEB/XAA-0000 DV218AEBXAA DV218AEBXAC DV218AES DV218AESXAC DV218AEW DV218AEW/XAA-0000 DV218AEWXAA DV218AEWXAC DV219AEB DV219AEB/XAA-0000 DV219AEBXAA DV219AEW DV219AEW/XAA-0000 DV219AEWXAA DV220AEW DV220AEW/XAA DV220AEWXAC DV221AEGXAC DV221AESXAC DV229AEG DV229AEGXAC DV231AEW DV231AEWXAA DV2C6BEW DV2C6BEW/XAA-0000 DV2C6BEWXAA DV2C6BEWXAC DV306BEW DV306BEWXAC DV306LEW DV306LEW/XAA DV306LEWXAC DV316HEC DV316HECXAC DV316LESXAA DV316LESXAC DV316LEW DV316LEW/XAA-0000 DV316LEWXAA DV316LEWXAC DV317AEG DV317AEG/XAA-0000 DV317AEGXAA DV317AEGXAC DV317AES DV317AES/XAA-0000 DV317AESXAA DV317AESXAC DV317AEW DV317AEW/XAA-0000 DV317AEWXAA DV317AEWXAC DV328AEG DV328AEG/XAA DV328AER DV328AER/XAA DV328AEW DV328AEW/XAA-0000 DV328AEWXAA DV330AEB DV330AEB/XAA DV330AEBXAA DV330AEW DV330AEW/XAA DV330AEWXAC DV331AER DV331AER/XAA-0000 DV331AERXAA DV331AEW DV331AEW/XAA-0000 DV331AEWXAA DV331AEWXAC DV337AEG DV337AEG/XAA-0000 DV337AEGXAA DV337AEGXAC DV337AEL DV337AEL/XAA-0000 DV337AELXAA DV337AELXAC DV337AER DV337AER/XAA-0000 DV337AERXAA DV337AERXAC DV337AEW DV337AEW/XAA-0000 DV337AEWXAA DV337AEWXAC DV338AEB DV338AEB/XAA-0000 DV338AEBXAA DV338AEW DV338AEW/XAA-0000 DV338AEWXAA DV339AEG DV339AEGXAC DV339AEL DV339AELXAC DV339AER DV339AERXAC DV339AES DV339AESXAC DV339AEW DV339AEWXAA DV339AEWXAC DV340AEG DV340AEGXAC DV340AER DV340AERXAC DV350AEG DV350AEGXAC DV350AEP DV350AEP/XAA-0000 DV350AEPXAA DV350AEPXAC DV350AER DV350AER/XAA-0000 DV350AERXAA DV350AERXAC DV350AEW DV350AEW/XAA-0000 DV350AEWXAA DV361EWBEWR DV361EWBEWRAC DV363EWBEUF DV365ETBGSF DV365ETBGSFAC DV365ETBGWR DV365ETBGWRAC DV36J4000EW DV393ETPARA DV393ETPARAA1 DV393ETPAWR DV393ETPAWRA1 DV393ETPAWRAC DV393GTPARA DV395ETPARA DV395ETPARAA1 DV395ETPASU DV395ETPAWR DV395ETPAWRA1 DV400EWHDR DV405ETPAGRAC DV405ETPASU DV405ETPASU/AA-0001 DV405ETPASUAA DV405ETPASUAC DV405ETPAWR DV405ETPAWR/AA-0001 DV405ETPAWRAA DV407AEW DV407AEWXAA DV409AER DV409AER/XAA-0000 DV409AERXAA DV409AEW DV409AEW/XAA-0000 DV409AEWXAA DV409SELXAC DV40J3000EW DV410AER DV410AER/XAA DV410AEW DV410AEW/XAA DV410AEWXAC DV419AES DV419AESXAC DV419AEU DV419AEU/XAA-0000 DV419AEUXAA DV419AEW DV419AEW/XAA-0000 DV419AEWXAA DV422EWHDR DV428AEL DV428AELXAC DV428AEW DV428AEWXAC DV42H5000EW DV42H5200EF DV42H5200EP DV42H5200EW DV42H5400EF DV42H5400EW DV42H5600EP DV42H5600GW DV431AEP DV431AEPXAA DV431AEPXAC DV431AEW DV431AEWXAA DV433ETGJWR DV438AEL DV438AELXAC DV438AER DV438AERXAA DV448AEE DV448AEE/XAA-0000 DV448AEEEXAA DV448AEP DV448AEP/XAA-0000 DV448AEPXAA DV448AEPXAC DV448AEW DV448AEW/XAA-0000 DV448AEWXAA DV448AEWXAC DV456ETHDSU DV456EWHDSU DV456EWHDR DV45H7000EP DV45H7000EW DV45H7200EP DV45H7400EP DV476ETHASU DV476ETHAWR DV484ETHASU DV484ETHASUA1 DV484ETHAWR DV484ETHAWRA1 DV48H7400EP DV48H7400EW DV501AEW DV501AEWXAA DV50F9A6EVW DV50F9A7EVP DV50F9A7EVW DV50F9A8EVP DV50F9A8EVW DV520AEP/XAA DV520AEW DV520AEW/XAA DV5451AEPXAC DV5451AEW DV5451AEWXAA DV5451AEWXAC DV5471AEP DV5471AEPXAA DV5471AEPXAC DV5471AEW DV5471AEWXAA DVE45N5300F DVE45N5300V DVE45N5300W DVE50M7450P DVE50M7450W

ALTERNATE PART NUMBERS:

AP4342351, DC97-08891A,
PS4220205

