

REFRIGERATOR WATER FILTER BASE

SD242009602

IMPORTANT: Unplug your appliance and turn off power at the breaker before servicing. Turn off the water supply. If you have doubts or are unfamiliar with this type of installation work, seek the services of a qualified Service Technician. Supplying Demand assumes no responsibility for the improper installation of this product.

POSSIBLE REASONS TO REPLACE A WATER FILTER BASE:

- Cracked and leaking water
- Broken release mechanism causing the filter to jam

TOOLS NEEDED:

- Torque 15
- Phillips Head Screwdriver
- Towel (optional)

INSTALLATION INSTRUCTIONS

1. Open the door of the refrigerator and (optional) lay down a towel beneath the water filter housing in case of water drips or leaks.
2. Remove the filter by pressing inward to release.
3. Remove the top shelf by lifting up and releasing the rear hooks.
4. Remove the light cover. Lift the cover and press on the hinge tabs on both side.
5. Unscrew the filter housing with the Torque 15 and slide off of the tracks to remove.
6. Remove the (4) mounting screws from the filter base.
7. Remove the water lines by pressing up on the locking collars and pulling the water lines from the water filter base.
8. Remove the base.
9. When reinstalling the new base, be sure that the locking tabs on the back of the base are locked into place properly.
 - a. Use a flat head screwdriver to press into the locking tab recesses.
 - b. Make sure they have clicked into place properly or the water filter will not catch when installing in Step 16.
10. Slide the new water filter base into place.
11. Reconnect the water lines exactly as they were removed.
12. Secure the base with the (4) mounting screws.
13. Slide the filter housing back into place on the tracks and secure with the screws.
14. Replace the light cover by snapping the hinge tabs back into place.
15. Put the shelf back into the refrigerator as it was removed.
16. Reinstall the water filter.