

**SD330190X4**

**SD330190X4**

## **4 PACK RANGE BURNER CONTROL KNOB**

### **COMPATIBLE MODELS:**

1745^0A 1745W0A 1765\*0A 1765^0A 1765W0A 2045B0A  
2045B1A 2065B0A 2065B1A 2065B2A 2274238591 2735\*0A  
2765\*0A 2765^0A 2765W0A B8758B0 B8758B1 B9307\*0  
B9307^0 B9307X0 B9308B0 B9308W0 B9457\*0 B9457^0  
B9457X0 B9458B0 RC8200XKCO RC8200XKDO RC8200XKGO  
RC8200XKH0 RC8200XKNO RC8200XKS0 RC8200XKW0  
RC8200XKW1 RC8400XKW1 RHM973PP0 RHM975PW  
RHM988PW RS600BXK0 RS600BXK1 RS600BXK2  
RS6100XKW0 RS6100XKW1 RS6100XKW2 RS6100XKW3  
RS610P XK0 RS610P XK1 RS610P XK2 RS610P XK3  
RS6300XKW0 RS6300XKW1 RS6300XKW2 RS6300XKW3  
RS630P XK0 RS630P XK1 RS630P XK2 RS630P XK3 RS660B XK0  
RS660B XK1 RS660B XK2 RS660B XK3 RS660B XK4  
RS6700XKW0 RS6700XKW1 RS6700XKW2 RS6700XKW3  
RS6700XKW4 RS670P XK0 RS670P XK1 RS670P XK2  
RS670P XK3 RS670P XK4 RS675P XK0 RS675P XK1

### **ALTERNATE PART NUMBERS:**

WP330190, AP6008016, 2842,  
328135, 329404, ER330190,  
PS11741145, WP330190VP

