

SD74011493

SD74011493

Electric Range Control Knob

COMPATIBLE MODELS:

JES8750BAB	JES8750BAB16	JES8750BAF
JES8750BAF16	JES8750BAS	JES8750BAS17
JES8850BAB	JES8850BAB19	JES8850BAF
JES8850BAF19	JES8850BAQ	JES8850BAS
JES8850BAS20	JES8850BCB	JES8850BCB20
JES8850BCS	JES8850BCS21	JES8850BCW
JES9750BAB	JES9750BAB17	JES9750BAS
JES9750BAS18	JES9750BAW	JES9750BAW17
JES9800BAB	JES9800BAF	JES9800BAS
JES9800BAS18	JES9800CAB17	JES9800CAF17
JES9860BAB	JES9860BAB18	JES9860BAS
JES9860BAS19	JES9860BAW	JES9860BAW18
JES9860BCB	JES9860BCS	JES9860BCW

ALTERNATE PART NUMBERS:

WP74011493, AP6011254, 1189038,
PS11744450

