

**SDW10506367X2**

**SDW10506367X2**

# Gas Range Burner Control Knob

## COMPATIBLE MODELS:

WGG555S0BB00 WGG555S0BB01 WGG555S0BB04  
WGG555S0BB06 WGG555S0BB07 WGG555S0BS00  
WGG555S0BS01 WGG555S0BS04 WGG555S0BS06  
WGG555S0BS07 WGG555S0BW00 WGG555S0BW01  
WGG555S0BW04 WGG555S0BW06 WGG555S0BW07  
WGG755S0BE00 WGG755S0BE01 WGG755S0BE03  
WGG755S0BE04 WGG755S0BE06 WGG755S0BE07  
WGG755S0BH00 WGG755S0BH01 WGG755S0BH03  
WGG755S0BH04 WGG755S0BH06 WGG755S0BH07  
WGG755S0BS00 WGG755S0BS01 WGG755S0BS03  
WGG755S0BS04 WGG755S0BS06 WGG755S0BS07

## ALTERNATE PART NUMBERS:

WPW10506367, AP6022440, PS11755773

