



SUPPLYING DEMAND®

**SDWB03T10079**

# SDWB03T10079

# Range Burner Control Knob

## COMPATIBLE MODELS:

JB900TK1WW JB900TK2WW JB900TK3WW JB900TK5WW JB900TK6WW JB900TKW JB900WD1WW JB905TH1WW  
 JB905TH2WW JB905TH3WW JB905TH4WW JB910TK1WW JB910TK2WW JB910TK3WW JB910TK4WW JB910TK5WW  
 JB910TK6WW JB910TKW JB940TD1WW JB940WB1WW JB940WB2WW JB940WB4WW JB960TB1WW JB960TB2WW  
 JB960TB4WW JB960WB1WW JB960WB2WW JB960WB4WW JB968TH1WW JB968TH2WW JB968TH3WW  
 JB968TH4WW JB968TK1WW JB968TK2WW JB968TK3WW JB968TK4WW JB968TK5WW JB968TKW JBP48WH1WW  
 JBP48WH2WW JBP48WH3WW JBP49WK1WW JBP49WK2WW JBP49WK3WW JBP49WK4WW JBP49WKW JBP79TD1WW  
 JBP79TD2WW JBP79WB1WW JBP79WB2WW JBP79WB4WW JBP79WB5WW JBP85TD1WW JBP85WB1WW  
 JBP85WB2WW JBP85WB4WW JBP90TF2WW JBP95TF2WW JBP99TH1WW JBP99TH2WW JCB800WK1WW  
 JCB800WK2WW JCB800WK3WW JCB800WK4WW JCB800WK5WW JCB900WK1WW JCB900WK2WW JCB900WK3WW  
 JCB900WK4WW JCB900WK5WW JCB905TJ1WW JCB905TJ2WW JCB905TJ3WW JCB905WJ1WW JCB905WJ2WW  
 JCB905WJ3WW JCB909TK1WW JCB909TK2WW JCB909TK3WW JCB909TK4WW JCB909TK5WW JCB909TK6WW  
 JCB909WK1WW JCB909WK2WW JCB909WK3WW JCB909WK4WW JCB909WK5WW JCB909WK6WW JCB910TK1WW  
 JCB910TK2WW JCB910TK3WW JCB910TK4WW JCB910TK5WW JCB910TK6WW JCB910WK1WW JCB910WK2WW  
 JCB910WK3WW JCB910WK4WW JCB910WK5WW JCB910WK6WW JCB968TJ1WW JCB968TJ2WW JCB968TJ3WW  
 JCB968TK1WW JCB968TK3WW JCB968TK4WW JCB968TK5WW JCB968TK6WW JCB968WJ1WW JCB968WJ2WW  
 JCB968WJ3WW JCB968WK1WW JCB968WK2WW JCB968WK3WW JCB968WK5WW JCB968WK6WW JCBP48WJ1WW  
 JCBP48WJ2WW JCBP48WJ3WW JCBP49WK1WW JCBP49WK2WW JCBP49WK3WW JCS905WK1WW JCS905WK2WW  
 JCS905WK3WW JCS905WK4WW JCS966TD1WW JCS966WD1WW JCS968TF1WW JCS968TF2WW JCS968TF3WW  
 JCS968TF4WW JCS968TF5WW JCS968TF6WW JCS968WK1WW JCS968WK2WW JCS968WK3WW JCS968WK4WW  
 JCS968WK5WW JCSP46WD1WW JCSP47WF1WW JCSP47WF2WW JCSP47WF3WW JCSP47WF4WW JCSP47WF5WW  
 JCSP47WF6WW JD900WK1WW JD900WK2WW JD900WK3WW JD900WK4WW JD900WKW JD966TD1WW  
 JD966TD2WW JD966WD1WW JD966WD2WW JD968TF1WW JD968TF2WW JD968TF3WW JD968TF4WW JD968TF5WW  
 JD968TF6WW JD968TK1WW JD968TK2WW JD968TK3WW JD968TK4WW JD968TK5WW JD968TKW JDP46WD2WW  
 JDP47WF1WW JDP47WF2WW JDP47WF3WW JDP47WF4WW JDP47WF5WW JDP47WF6WW JS900WK1WW  
 JS900WK2WW JS900WK3WW JS900WKW JS905TK1WW JS905TK2WW JS905TK3WW JS905TK4WW JS905TKW  
 JS966TD1WW JS966TD2WW JS966WD1WW JS966WD2WW JS968TF1WW JS968TF2WW JS968TF3WW JS968TF4WW  
 JS968TF5WW JS968TF6WW JS968TK1WW JS968TK2WW JS968TK3WW JS968TK4WW JS968TK5WW JS968TKW  
 JS998TH1WW JS998TK1WW JS998TK3WW JSP46WD2WW JSP47WF1WW JSP47WF2WW JSP47WF3WW JSP47WF4WW  
 JSP47WF5WW JSP47WF6WW JSP56WD1WW JSP56WD2WW JSP57WF1WW JSP57WF2WW JSP57WF3WW PB750DN1WW  
 PB750TN1WW PB900TP1WW PB900TP2WW PB900TP3WW PB900TP4WW PB900TP5WW PB909TP1WW  
 PB909TP2WW PB909TP3WW PB909TP4WW PB909TP5WW PB909TP6WW PB910TP1WW PB910TP2WW PB910TP3WW  
 PB910TP4WW PB970TM1WW PB970TM2WW PB970TM3WW PB970TP1WW PB970TP2WW PB970TP3WW PB970TP4WW  
 PB975TM1WW PB975TM2WW PB975TP1WW PB975TP2WW PB975TP3WW PB975TP4WW PB976TN1WW PCB800DP1WW  
 PCB800DP2WW PCB900DP1WW PCB900DP2WW PCB909DP1WW PCB909DP2WW PCB909DP3WW PCB969DP1WW  
 PCB969DP2WW PCB969DP3WW PCB975DN1WW PCB975DP1WW PCB975DP2WW PCB975DP3WW PCB975DP4WW  
 PCS905DP1WW PCS905DP2WW PCS968DP1WW PCS968DP2WW PD900DP1WW PD900DP2WW PD900DP3WW  
 PD968TP1WW PD968TP2WW PD968TP3WW PS900DP1WW PS900DP2WW PS905TP1WW PS905TP2WW PS905TP3WW  
 PS968TP1WW PS968TP2WW PS968TP3WW

## ALTERNATE PART NUMBERS:

AP2015112, AH226413, EA226413, PS226413,  
WB3T10079

