

SDWB20X10048

SDWB20X10048

MICROWAVE THERMOSTAT

COMPATIBLE MODELS:

CSA1201RSS01 CSA1201RSS02 CSA1201RSS03 CSA1201RSS04 CSA1201RSS05 CSB9120SJ1SS CSB9120SJ2SS
CSB9120SJ4SS CSB912M2N1S5 CSB912M2N2S5 CSB912P2N1S1 CSB912P2N2S1 CSB913M2N1S5 CSB913M2N2S5
CSB913P2N1S1 CSB913P2N2S1 CSB913P3N1D1 CSB913P3N2D1 CSB913P4N1W2 CSB913P4N2W2 CSB923M2N1S5
CSB923M2N2S5 CSB923P2N1S1 CSB923P2N2S1 CSB923P3N1D1 CSB923P3N2D1 CSB923P4N1W2 CSB923P4N2W2
CT9800SH1SS CT9800SH2SS CT9800SH3SS CT9800SH4SS CT9800SH5SS CT9800SH6SS CT9800SJ2SS
CTC912P2N1S1 CVM1750SH1SS CVM1750SH2SS CVM1790SS1SS CVM1790SS2SS CVM1790SS3SS CVM1790SS4SS
CVM1790XS1SL CVM1790XS2SL CWB7030SL1SS CWB7030SL2SS CWB7030SL3SS CWB713P2N1S1 CWB713P2N2S1
JK3800DH1BB JK3800DH1WW JK3800DH2BB JK3800DH2WW JK3800DH3BB JK3800DH3WW JK3800DH4BB
JK3800DH4WW JK3800DH5BB JK3800DH5WW JK3800DH6BB JK3800DH6WW JK3800DH7WW JK3800DH8BB
JK3800SH1SS JK3800SH2SS JK3800SH3SS JK3800SH4SS JK3800SH5SS JK3800SH6SS JK3800SH7SS
JK3800SH8SS JT3800DH1BB JT3800DH2BB JT3800DH3BB JT3800DH4BB JT3800DH5BB JT3800DH6BB
JT3800DH7BB JT3800DH8BB JT3800SH1SS JT3800SH2SS JT3800SH3SS JT3800SH4SS JT3800SH5SS
JT3800SH6SS JT3800SH7SS JT3800SH8SS JVM6172DK5BB JVM6172DK5WW JVM6172SK5SS JVM6175BL5TS
JVM6175BL6TS JVM6175DK5BB JVM6175EK5ES JVM6175SK5SS JVM6175YK5FS PK7800EK1ES PK7800EK2ES
PK7800EK3ES PK7800EK4ES PK7800EK5ES PK7800EK6ES PK7800SK1SS PK7800SK2SS PK7800SK3SS PK7800SK4SS
PK7800SK5SS PK7800SK6SS PSA1200RBB01 PSA1200RBB02 PSA1200RWW01 PSA1201RSS01 PSA2200RBB01
PSA2200RBB02 PSA2200RBB03 PSA2200RWW01 PSA2200RWW02 PSA2201RSS01 PSA2201RSS02 PSA9120DF1BB
PSA9120DF1WW PSA9120SF1SS PSA9120SF2SS PSA9120SF3SS PSA9120SF4SS PSA9120SF5SS PSA9120SF6SS
PSA9240DF1BB PSA9240DF1WW PSA9240SF1SS PSA9240SF2SS PSA9240SF3SS PSA9240SF5SS PSA9240SF6SS
PSB9100BL2TS PSB9100BL3TS PSB9100DF1BB PSB9100DF1WW PSB9100DF2BB PSB9100DF2WW PSB9100DF3BB
PSB9100DF3WW PSB9100EF1ES PSB9100EF3ES PSB9100EF4ES PSB9100SF1SS PSB9100SF2SS PSB9100SF3SS
PSB9100SF5SS PSB9100SF6SS PSB9120BL2TS PSB9120BL3TS PSB9120DF1BB PSB9120DF1WW PSB9120DF2BB
PSB9120DF2WW PSB9120DF3BB PSB9120DF3WW PSB9120SF1SS PSB9120SF2SS PSB9120SF3SS PSB9120SF4SS
PSB9120SF5SS PSB9120SF6SS PSB9240EF1ES PSB9240EF3ES PSB9240EF4ES PT7800DH1BB PT7800DH1WW
PT7800DH2BB PT7800DH2WW PT7800DH3BB PT7800DH3WW PT7800DH4BB PT7800DH4WW PT7800DH5BB
PT7800DH5WW PT7800DH6BB PT7800DH6WW PT7800DH7BB PT7800DH7WW PT7800DH8BB PT7800DH8WW
PT7800DH9BB PT7800DH9WW PT7800EK4ES PT7800EK5ES PT7800EK6ES PT7800EK7ES PT7800EK8ES
PT7800EK9ES PT7800SH1SS PT7800SH2SS PT7800SH3SS PT7800SH4SS PT7800SH5SS PT7800SH6SS
PT7800SH7SS PT7800SH8SS PT9800SH1SS PT9800SH2SS PT9800SH3SS PT9800SH4SS PT9800SH5SS
PT9800SH6SS PT9800SH7SS PT9800SH8SS PT9800SH9SS PVM1790DR1BB PVM1790DR1CC PVM1790DR1WW
PVM1790SR1SS PVM9179DF1BB PVM9179DF1CC PVM9179DF1WW PVM9179DF2BB PVM9179DF2WW
PVM9179DF3BB PVM9179DF3WW PVM9179EF1ES PVM9179EF2ES PVM9179EF3ES PVM9179SF1SS PVM9179SF2SS
PVM9179SF3SS PWB7027EL1ES PWB7027SL1SS PWB7030EL1ES PWB7030EL2ES PWB7030EL3ES PWB7030EL4ES
PWB7030SL1SS PWB7030SL2SS PWB7030SL3SS PWB7030SL4SS ZSA1201J1SS ZSA1201J2SS ZSA1201J3SS
ZSA1201J4SS ZSA1201RSS01 ZSA1202J1SS ZSA1202J2SS ZSA1202J3SS ZSA1202J4SS ZSA1202RSS01 ZSA2201RSS01
ZSA2201RSS02 ZSB9121N1SS ZSB9121N2SS ZSB9131N2SS ZSB9132N1SS ZSB9132N2SS ZSB9231N1SS ZSB9231N2SS
ZSB9232N1SS ZSB9232N2SS ZSC1001J1SS ZSC1001J2SS ZSC1001J4SS ZSC1201J1SS ZSC1201J2SS ZSC1201J4SS
ZSC1202J1SS ZSC1202J2SS ZSC1202J4SS ZSC2201J1SS ZSC2201J2SS ZSC2201J4SS ZSC2202J1SS ZSC2202J4SS

ALTERNATE PART NUMBERS:

AP5176812, AH3491479,
EA3491479, PS3491479

