

**SDWB24T10134**

# **SDWB24T10134 CLOTHES DRYER TIMER**

## **COMPATIBLE MODELS:**

CP350ST1SS CP350ST2SS CP650ST1SS CP650ST2SS JCS630DF1BB JCS630DF1WW JCS630DF2WW JCS630SF1SS  
JCS860DF1BB JCS860DF1WW JCS860EF1ES JCS860SF1SS JCS905BK3BB JCS905BK4BB JCS905SK3SS  
JCS905SK4SS JCS905WK3WW JCS905WK4WW JCS968BK4BB JCS968BK5BB JCS968SK3SS JCS968SK4SS  
JCS968SK5SS JCS968WK4WW JCS968WK5WW JCSP41SV1SS JCSP41SV2SS JCSP41SV3SS JCSP42BK3BB  
JCSP42BK4BB JCSP42DN1BB JCSP42DN1WW JCSP42DN2BB JCSP42DN2WW JCSP42DN3BB JCSP42DN3WW  
JCSP42DR1BB JCSP42DR1WW JCSP42DR2BB JCSP42DR2WW JCSP42DR3WW JCSP42DR4BB JCSP42DR4WW  
JCSP42SK3SS JCSP42SK4SS JCSP42SN1SS JCSP42SN2SS JCSP42SN3SS JCSP42SR1SS JCSP42SR2SS JCSP42SR3SS  
JCSP42WK3WW JCSP42WK4WW JCSP46DP1BB JCSP46DP1WW JCSP46DP2BB JCSP46DP2WW JCSP46DR1BB  
JCSP46DR1WW JCSP46DR2BB JCSP46DR2WW JCSP46DR3WW JCSP46DR4BB JCSP46DR4WW JCSP46SP1SS  
JCSP46SP2SS JCSP46SR1SS JCSP46SR2SS JCSP46SR3SS JD630DF1BB JD630DF1WW JD630DF2BB JD630DF2WW  
JD630SF1SS JD630SF2SS JD900BK3BB JD900BK4BB JD900CK3CC JD900CK4CC JD900WK3WW JD900WK4WW  
JD968BK4BB JD968BK5BB JD968KK4CC JD968SK5SS JD968SK6SS JD968TK4WW JD968TK5WW JDP42DT1BB  
JDP42DT1WW JDP42ST1SS JP656DD1BB JP656DD1WW JP656SD1SS JS630DF1BB JS630DF1CC JS630DF1WW  
JS630DF2BB JS630DF2CC JS630DF2WW JS630SF1SS JS630SF2SS JS900BK3BB JS900CK3CC JS900SK4SS  
JS900WK3WW JS905BK3BB JS905BK4BB JS905SK4SS JS905SK5SS JS905TK3WW JS905TK4WW JS968BK4BB  
JS968BK5BB JS968KK4CC JS968KK5CC JS968SK5SS JS968SK6SS JS968TK4WW JS968TK5WW JSP42BK4BB  
JSP42BK5BB JSP42CK4CC JSP42CK5CC JSP42DN1BB JSP42DN1CC JSP42DN1WW JSP42DN2BB JSP42DN2CC  
JSP42DN2WW JSP42DN3BB JSP42DN3CC JSP42DN3WW JSP42DN4BB JSP42DN4CC JSP42DN4WW JSP42SK5SS  
JSP42SN1SS JSP42SN2SS JSP42SN3SS JSP42SN4SS JSP42WK4WW JSP42WK5WW JSP46BN1BB JSP46CN1CC  
JSP46DN1BB JSP46DN1WW JSP46DP1BB JSP46DP1WW JSP46DP2BB JSP46DP2WW JSP46DP3BB JSP46DP3WW  
JSP46SN1SS JSP46SP1SS JSP46SP2SS JSP46SP3SS JSP46WN1WW MBC12GAZWW PCS905DP1BB PCS905DP1WW  
PCS905DP2BB PCS905DP2WW PCS905DR1BB PCS905DR1WW PCS905SP1SS PCS905SP2SS PCS905SR1SS  
PCS968DP1BB PCS968DP1WW PCS968DP2BB PCS968DP2WW PCS968DR1BB PCS968DR1WW PCS968SP1SS  
PCS968SP2SS PCS968SR1SS PD900DP1BB PD900DP1CC PD900DP1WW PD900DP2BB PD900DP2CC  
PD900DP2WW PD900DP3BB PD900DP3CC PD900DP3WW PD968DP1BB PD968DP2BB PD968DP3BB PD968SP1SS  
PD968SP2SS PD968SP3SS PD968TP1WW PD968TP2WW PD968TP3WW PDT760SSFSS PP944DT1BB PP944ST1SS  
PP944TT1WW PP962BM1BB PP962BM2BB PP962BM3BB PP962EH1ES PP962KM1CC PP962KM2CC PP962SM1SS  
PP962SM2SS PP962SM3SS PP962TM1WW PP962TM2WW PP962TM3WW PP972BM1BB PP972BM2BB PP972BM3BB  
PP972KM1CC PP972KM2CC PP972KM3CC PP972SM1SS PP972SM2SS PP972SM3SS PP972TM1WW PP972TM2WW  
PS900DP1BB PS900DP1CC PS900DP1WW PS900DP2BB PS900DP2CC PS900DP2WW PS900SP1SS PS900SP2SS  
PS905DP1BB PS905DP2BB PS905DP3BB PS905SP1SS PS905SP2SS PS905SP3SS PS905TP1WW PS905TP2WW  
PS905TP3WW PS968DP1BB PS968DP2BB PS968DP3BB PS968SP1SS PS968SP2SS PS968SP3SS PS968TP1CC  
PS968TP1WW PS968TP2CC PS968TP2WW PS968TP3CC PS968TP3WW ZEU36KKB2BB ZEU36KSK2SS ZEU36KSK3SS  
ZEU36KWK2WW

## **ALTERNATE PART NUMBERS:**

**AP3993773, AH1481076,  
EA1481076, PS1481076**

