

SDWB30T10132



SDWB30T10132

Microwave Mounting Plate Bracket

COMPATIBLE MODELS:

CES700M2N1S5 CES700M2N2S5 CES750M2N1S5 CES750M2N2S5 EER2000M02BB EER2000M02CC EER2000M02WW
 EER2001M02SS EER2002M02BS JB400DP1BB JB400DP1WW JB400DP2BB JB400DP2WW JB400DP3BB JB400DP3WW
 JB400DP4BB JB400DP4WW JB400DP5BB JB400DP5WW JB400DP6BB JB400DP6WW JB400SP1SS JB400SP2SS JB400SP3SS
 JB400SP4SS JB400SP5SS JB400SP6SS JB400SP7SS JB400SP8SS JB620BR3WH JB620BR4WH JB620BR5WH JB620DF1BB
 JB620DF1WW JB620DF2BB JB620DF2WW JB620DF4BB JB620DF4WW JB620DR1BB JB620DR1WW JB620DR2WW JB620DR3WW
 JB620DR3BB JB620DR3WW JB620DR4BB JB620DR4WW JB620DR5BB JB620DR5WW JB620GF1SA JB620GF2SA JB620GF4SA
 JB620GR1SA JB620GR2SA JB620GR3SA JB620GR4SA JB620GR5SA JB620RF1SS JB620RF2SS JB620RF4SS JB620SR1SS
 JB620SR2SS JB620SR3SS JB620SR4SS JB620SR5SS JB620SR6SS JB620SR7SS JB625DK1BB JB625DK1WW JB625DK2BB
 JB625DK2WW JB625DK3BB JB625DK3WW JB625DK4BB JB625DK4WW JB625DK5BB JB625DK5WW JB625DK6WW JB625GK1SA
 JB625GK2SA JB625GK3SA JB625GK4SA JB625GK5SA JB625GK6SA JB625RK1SS JB625RK2SS JB625RK3SS JB625RK4SS
 JB625RK5SS JB625RK6SS JB630DF1BB JB630DF1WW JB630DF2BB JB630DF2WW JB630DF4BB JB630DF4WW JB630DF5BB
 JB630DF5WW JB630RF1SS JB630RF2SS JB630RF4SS JB630RF5SS JB640DF1BB JB640DF1CC JB640DF1WW JB640DF2BB
 JB640DF2CC JB640DF2WW JB640DF5BB JB640DF5CC JB640DF5WW JB640DF6BB JB640DF6CC JB640DF6WW JB640DIR1WW
 JB640DIR2WW JB640DIR3WW JB640DIR4BB JB640DIR4WW JB640DIR5BB JB640DIR5WW JB640DIR6BB JB640DIR6WW
 JB640DN1BB JB640DN1CC JB640DN1WW JB640DP1BB JB640DP1CC JB640DP1WW JB640DR1BB JB640DR1CC JB640DR1WW
 JB640DR2BB JB640DR2CC JB640DR2WW JB640DR3BB JB640DR3CC JB640DR3WW JB640DR4BB JB640DR4CC JB640DR4WW
 JB640DR5BB JB640DR5CC JB640DR5WW JB640DR6BB JB640DR6CC JB640DR6WW JB640MN1BS JB640MP1BS JB640MP2BS
 JB640MR1BS JB640MR2BS JB640MR3BS JB640MR4BS JB640MR5BS JB640RF1SS JB640SF1SS JB640SF2SS JB640SF3SS
 JB640SF5SS JB640SF6SS JB640SIR5SS JB640SIR6SS JB640SIR7SS JB640SIR8SS JB640SN1SS JB640SP1SS JB640SP2SS
 JB640SR1SS JB640SR2SS JB640SR3SS JB640SR4SS JB640SR5SS JB640SR6SS JB640SR7SS JB640SR8SS JB670DP1BB
 JB670DP1WW JB670DP2BB JB670DP2WW JB670DP3BB JB670DP3WW JB670SP1SS JB670SP2SS JB670SP3SS JB670SP4SS
 JB670SP5SS JB690DN1BB JB690DN1WW JB690DN2BB JB690DN2WW JB690DN3BB JB690DN3WW JB690DN4BB JB690DN4WW
 JB750DF1BB JB750DF1CC JB750DF1WW JB750DF2BB JB750DF2CC JB750DF2WW JB750DF3BB JB750DF3CC JB750DF3WW
 JB750DF4BB JB750DF4CC JB750DF4WW JB750EF1ES JB750EF2ES JB750EF3ES JB750EF4ES JB750SF1SS JB750SF2SS JB750SF3SS
 JB750SF4SS JB770DP1BB JB770DP1WW JB770SP1SS JB770TP1WW JB850DP1BB JB850DP1WW JB850DP2BB JB850DP2WW
 JB850DP3BB JB850DP3WW JB850DP4BB JB850DP4WW JB850SP1SS JB850SP2SS JB850SP3SS JB850SP4SS JB855DP1BB
 JB855DP1WW JB855DP2BB JB855DP2WW JB855DP3BB JB855DP3WW JB855DP4BB JB855DP4WW JB855SP1SS JB855SP2SS
 JB855SP3SS JB855SP4SS JB870DF1BB JB870DF2BB JB870DF3BB JB870DF4BB JB870SF1SS JB870SF2SS JB870SF4SS
 JB870TF1WW JB870TF2WW JB870TF3WW JB870TF4WW JB988BK6BB JB988KK6CC JB988SK6SS JB988TK6WW JBP62BM2WH
 JBP62BM3WH JBP62BM4WH JBP62BM5WH JBP62DM2BB JBP62DM2WW JBP62DM3BB JBP62DM3WW JBP62DM4WW
 JBP62DM5WW JBP62SN1SS JBP62SN2SS JBP64DM2CC JBP64DM2WW JBP65DM2BB JBP65DM2WW JBP65DM2SS JBP65DM2SS
 JBP66DM2BB JBP66DM2CC JBP66DM2WW JBP66DM3BB JBP66DM3CC JBP66DM3WW JBP66DM4BB JBP66DM4CC
 JBP66DM4WW JBP66DM5BB JBP66DM5CC JBP66DM5WW JBP66DM6BB JBP66DM6CC JBP66DM6WW JBP66MN1BS
 JBP66MN2BS JBP66MN3BS JBP66MN4BS JBP66MN5BS JBP66MN6BS JBP66SM2SS JBP66SM3SS JBP66SM4SS JBP66SM5SS
 JBP66SM6SS JBP66SM7SS JBP66SM8SS JBP66SM9SS JBS55DM2BB JBS55DM2CC JBS55DM2WW JBS55DM3BB JBS55DM3WW
 JBS55DM4BB JBS55DM4WW JBS55DM5BB JBS55DM5WW JBS55DM6BB JBS55DM6WW JBS55MM3BS JBS55MM4BS JBS55MM5BS
 JBS55MM6BS JBS55SM2SS JBS55SM3SS JBS55SM4SS JBS55SM5SS JBS55SM6SS JBS55SM7SS JBS55SM8SS JBS55SM9SS
 JBS60DF1BB JBS60DF1WW JBS60DF2BB JBS60DF2WW JBS60DF3BB JBS60DF3WW JBS60DF4BB JBS60DF4WW JBS60DK1BB
 JBS60DK1WW JBS60DK2BB JBS60DK2WW JBS60DK3BB JBS60DK3WW JBS60DK4BB JBS60DK4WW JBS60DK5BB JBS60DK5WW
 JBS60RF1SS JBS60RF2SS JBS60RF3SS JBS60RF4SS JBS60RK1SS JBS60RK2SS JBS60RK3SS JBS60RK4SS JBS60RK5SS
 JBS60RK6SS JBS65DF1BB JBS65DF1WW JBS65RF1SS JCB850DR1WW JCB850DR2WW JCB850SR1SS JCB850SR2SS
 JCBP62DM2WW JCBP65DM2WW JCBP65MM2BS JCBP65SM2SS JCBP66DM2BB JCBP66DM2WW JCBP66SM2SS JCBP66SM2SS
 JCS630DF2WW JCS630DF3WW JCSP42BK3BB JCSP42BK4BB JCSP42DN1BB JCSP42DN1WW JCSP42DN2BB JCSP42DN2WW
 JCSP42DN3BB JCSP42DN3WW JCSP42SK3SS JCSP42SK4SS JCSP42SN1SS JCSP42SN2SS JCSP42SN3SS JCSP42WK3WW
 JCSP42WK4WW JD630DF1BB JD630DF1WW JD630DF2BB JD630DF2WW JD630DF3BB JD630DF3WW JD630DF4BB JD630DF4WW
 JD630DF5BB JD630DF5WW JD630DF6BB JD630DF6WW JD630DF7BB JD630DF7WW JD630DF8BB JD630DF8WW JD630DF9BB
 JD630DF9WW JD630SF1SS JD630SF2SS JD630SF3SS JD630SF4SS JD630SF5SS JD630SF6SS JD630SF7SS JD630SF8SS
 JD630SF9SS JD750DF1BB JD750DF2BB JD750SF1SS JD750SF2SS JD750SF3SS JD900BK3BB JD900BK4BB JD900CK3CC
 JD900CK4CC JD900WK3WW JD900WK4WW JDP42DT1BB JDP42DT1WW JDP42ST1SS JDP42ST1SS JP340BM2BB JP655BM2BB JP655M2SS
 JP655TM2WW JP656DD1BB JP656DD1WW JP656DD2BB JP656DD2BV JP656DD2WW JP656SD1SS JP656SD2SS JS630DF1BB
 JS630DF1CC JS630DF1WW JS630DF2BB JS630DF2CC JS630DF2WW JS630DF3BB JS630DF3CC JS630DF3WW JS630DF4BB
 JS630DF4CC JS630DF4WW JS630DF5BB JS630DF5CC JS630DF5WW JS630SF1SS JS630SF2SS JS630SF3SS JS630SF4SS
 JS630SF5SS JS750DF1BB JS750DF1WW JS750DF2BB JS750DF2WW JS750DF3BB JS750DF3WW JS750DF4BB JS750DF4WW
 JS750EF1ES JS750EF2ES JS750EF3ES JS750EF4ES JS750SF1SS JS750SF2SS JS750SF3SS JS750SF4SS JS900BK3BB JS900BK4BB
 JS900CK3CC JS900CK4CC JS900SK4SS JS900SK5SS JS900WK3WW JS900WK4WW JS998SK4SS JSP42BK5BB JSP42CK5CC
 JSP42DN1BB JSP42DN1CC JSP42DN1WW JSP42DN2BB JSP42DN2CC JSP42DN2WW JSP42DN3BB JSP42DN3CC JSP42DN3WW
 JSP42DN4BB JSP42DN4CC JSP42DN4WW JSP42SK5SS JSP42SN1SS JSP42SN2SS JSP42SN3SS JSP42SN4SS JSP42WK5WW
 PB750DN1BB PB750DN1WW PB750TN1WW PB920DP1BB PB920DP2BB PB920DP3BB PB920DP4BB PB920DP5BB PB920DT1BB
 PB920SP1SS PB920SP2SS PB920SP3SS PB920SP4SS PB920SP5SS PB920ST1SS PB920ST2SS PB920TP1WW PB920TP2WW

COMPATIBLE MODELS CONTINUED:

PB920TP3WW PB920TP4WW PB920TP5WW PB930DF1BB PB930DF2BB PB930DH1BB PB930DH2BB PB930DH3BB PB930SF1SS
 PB930SF2SS PB930SH1SS PB930SH2SS PB930SH3SS PB930SJ1SS PB930SJ2SS PB930SJ3SS PB930SJ4SS PB930SL1SS
 PB930SL2SS PB930SL3SS PB930SL4SS PB930TF1WW PB930TF2WW PB930TH1WW PB930TH2WW PB930TH3WW PB950SF1SS
 PB950SF2SS PB950SF4SS PB955SF1SS PB960BJ4TS PB960BJ5TS PB960BJ6TS PB960BJ7TS PB960BJ8TS PB960BJ9TS
 PB960DJ1BB PB960DJ2BB PB960DJ3BB PB960EJ1ES PB960EJ2ES PB960EJ3ES PB960EJ4ES PB960EJ5ES PB960EJ6ES
 PB960EJ7ES PB960FJ4DS PB960FJ5DS PB960FJ6DS PB960FJ7DS PB960FJ8DS PB960SJ1SS PB960SJ2SS PB960SJ3SS
 PB960SJ4SS PB960SJ5SS PB960SJ6SS PB960SJ7SS PB960SJ9SS PB960TJ1WW PB960TJ2WW PB960TJ3WW PB978DP1BB
 PB978DP2BB PB978DP3BB PB978DP4BB PB978DT1BB PB978SP1SS PB978SP2SS PB978SP3SS PB978SP4SS PB978SP5SS
 PB978SP6SS PB978ST1SS PB978TP1WW PB978TP2WW PB978TP3WW PB978TP4WW PB979DP1BB PB979DP2BB PB979DP3BB
 PB979DP4BB PB979SP1SS PB979SP2SS PB979SP3SS PB979SP4SS PB979SP5SS PB979SP6SS PB979ST1SS PB979TP1WW
 PB979TP2WW PB979TP3WW PB979TP4WW PB980SJ1SS PB980SJ2SS PB980SJ3SS PB980SJ4SS PB980SJ5SS PB980SJ7SS
 PB980SJ8SS PCB920SR1SS PCB920SR2SS PCB920SR3SS PCB920ST1SS PCB920ST2SS PCB950SF1SS PCB950SF2SS
 PCB950SF4SS PCB980SJ1SS PCB980SJ2SS PCB980SJ3SS PCB980SJ4SS PCB980SJ5SS PCB980SJ6SS PCB980SJ7SS
 PCB980SJ8SS PD900DP1BB PD900DP1CC PD900DP1WW PD900DP2BB PD900DP2CC PD900DP2WW PD900DP3BB
 PD900DP3CC PD900DP3WW PS900DP1BB PS900DP1CC PS900DP1WW PS900DP2BB PS900DP2CC PS900DP2WW PS900SP1SS
 PS900SP2SS PS920SF1SS PS920SF2SS PS920SF3SS PS950EF1ES PS950EF3ES PS950SF1SS PS950SF2SS PS950SF3SS
 PS960BL1TS PS960BL2TS PS960BL3TS PS960BL4TS PS960BL5TS PS960EL1ES PS960EL2ES PS960EL3ES PS960EL4ES
 PS960FL1DS PS960FL2DS PS960FL3DS PS960FL4DS PS960SL1SS PS960SL2SS PS960SL3SS PS960SL4SS PS960SL5SS
 PS960YP1FS PS978ST1SS PSS93BP1TS PSS93YP1FS XB625DK4WW XB625DK5BB XB625DK5WW XB625RK5SS

ALTERNATE PART NUMBERS:

AP4416172, 1536600, AH2321566,
 EA2321566, PS2321566

