



SUPPLYING DEMAND®

SDWB30T10145

SDWB30T10145

5-1/2 INCH RANGE SURFACE ELEMENT

COMPATIBLE MODELS:

CBC980ST2SS CCS975SD2SS CCS975SD3SS CEP70302M1S1 CEP70303M1S2 CEP70362M1S1 CEP70363M1S2 CEP90301N1BB
 CEP90302N1SS CEP90361N1BB CEP90362N1SS CES700P2M1S1 CES700P3M1D1 CES700P4M1W2 CES750M2N1S5 CES750M2N2S5
 CES750P2M1S1 CES750P3M1D1 CES750P4M1W2 CP350ST1SS CP350ST2SS CP350ST3SS CP650ST1SS CP650ST2SS CP650ST3SS
 CP9530S1SS CP9530S2SS CP9536S1SS CP9536S2SS CS975SD2SS CS975SD3SS CS980ST4SS CS980ST5SS CS980ST6SS
 CS980ST7SS CS980ST8SS JAS640RM2SS JB620DF1BB JB620DF1WW JB620DF2BB JB620DF2WW JB620DF4BB JB620DF4WW
 JB620GF1SA JB620GF2SA JB620GF4SA JB620RF1SS JB620RF2SS JB620RF4SS JB625DK1BB JB625DK1WW JB625DK2BB
 JB625DK2WW JB625DK3BB JB625DK3WW JB625DK4BB JB625DK4WW JB625DK5BB JB625DK5WW JB625DK6BB JB625DK6WW
 JB625GK1SA JB625GK2SA JB625GK3SA JB625GK4SA JB625GK5SA JB625GK6SA JB625RK1SS JB625RK2SS JB625RK3SS
 JB625RK4SS JB625RK5SS JB625RK6SS JB630DF1BB JB630DF1WW JB630DF2BB JB630DF2WW JB630DF4BB JB630DF4WW
 JB630DF5BB JB630DF5WW JB630RF1SS JB630RF2SS JB630RF4SS JB630RF5SS JB640DF1BB JB640DF1CC JB640DF1WW
 JB640DF2BB JB640DF2CC JB640DF2WW JB640DF5BB JB640DF5CC JB640DF5WW JB640DF6BB JB640DF6CC JB640DF6WW
 JB640RF1SS JB640SF1SS JB640SF2SS JB640SF3SS JB640SF5SS JB640SF6SS JB645DK1BB JB645DK1WW JB645DK2BB
 JB645DK2WW JB645DK3BB JB645DK3WW JB645DK4BB JB645DK4WW JB645DK5BB JB645DK5WW JB645DK6BB JB645DK6WW
 JB645EK1ES JB645EK2ES JB645EK3ES JB645EK4ES JB645EK5ES JB645EK6ES JB645FK3DS JB645FK4DS JB645FK5DS
 JB645FK6DS JB645RK1SS JB645RK2SS JB645RK3SS JB645RK4SS JB645RK5SS JB645RK6SS JB650DF1BB JB650DF1CC
 JB650DF1WW JB650DF2BB JB650DF2CC JB650DF2WW JB650DF4BB JB650DF4CC JB650DF4WW JB650DF5BB JB650DF5CC
 JB650DF5WW JB650DF1BB JB650DF1WW JB650EF1ES JB650EF2ES JB650EF4ES JB650EF5ES JB650SF1SS JB650SF2SS
 JB650SF4SS JB650SF5SS JB650SF1SS JB655DK1BB JB655DK1CC JB655DK1WW JB655DK2BB JB655DK2CC JB655DK2WW
 JB655DK3BB JB655DK3CC JB655DK3WW JB655DK4BB JB655DK4CC JB655DK4WW JB655DK5BB JB655DK5CC JB655DK5WW
 JB655DK6BB JB655DK7BB JB655DK7CC JB655DK7WW JB655EK1ES JB655EK2ES JB655EK3ES JB655EK4ES JB655EK5ES
 JB655EK7ES JB655FK3DS JB655FK4DS JB655FK5DS JB655FK7DS JB655SK1SS JB655SK2SS JB655SK3SS JB655SK4SS JB655SK5SS
 JB655SK6SS JB655SK7SS JB655YK6FS JB690DF1BB JB690DF1WW JB690DF2BB JB690DF2WW JB690DF4BB JB690DF4WW
 JB690DF1BB JB690DF1WW JB690EF1ES JB690EF2ES JB690EF4ES JB690SF1SS JB690SF2SS JB690SF4SS JB690SF1SS
 JB695DF1BB JB695DF1WW JB695EF1ES JB695SF1SS JB700DJ1BB JB700DJ1WW JB700DJ2BB JB700DJ2WW JB700DJ3BB
 JB700DJ3WW JB700DJ4BB JB700DJ4WW JB700DJ5BB JB700DJ5WW JB700EJ1ES JB700EJ2ES JB700EJ3ES JB700EJ4ES
 JB700EJ5ES JB700S1SS JB700S2SS JB700S3SS JB700S4SS JB700S5SS JB735DP1BB JB735DP1WW JB735FP1DS
 JB740DF1BB JB740DF1WW JB740DF2BB JB740DF2WW JB740SF1SS JB740SF2SS JB745DF1BB JB745DF1WW JB745DF2BB
 JB745DF2WW JB745DF3BB JB745DF3WW JB745EF1ES JB745EF2ES JB745EF3ES JB745SF1SS JB745SF2SS JB745SF3SS JB750BJ5TS
 JB750BJ6TS JB750BJ7TS JB750BJ8TS JB750DF1BB JB750DF1CC JB750DF1WW JB750DF2BB JB750DF2CC JB750DF2WW
 JB750DF3BB JB750DF3CC JB750DF3WW JB750DF4BB JB750DF4CC JB750DF4WW JB750DJ1BB JB750DJ1CC JB750DJ1WW
 JB750DJ2BB JB750DJ2CC JB750DJ2WW JB750DJ3BB JB750DJ3CC JB750DJ3WW JB750DJ4BB JB750DJ4WW JB750DJ5BB
 JB750DJ5WW JB750DJ6BB JB750DJ6WW JB750DJ7BB JB750DJ7WW JB750DJ8BB JB750DJ8WW JB750DJ9BB JB750DJ9WW
 JB750EF1ES JB750EF2ES JB750EF3ES JB750EF4ES JB750EJ1ES JB750EJ2ES JB750EJ3ES JB750EJ4ES JB750EJ5ES JB750EJ6ES
 JB750EJ7ES JB750EJ8ES JB750EJ9ES JB750FJ4DS JB750FJ5DS JB750FJ6DS JB750FJ7DS JB750FJ8DS JB750FJ9DS JB750SF1SS
 JB750SF2SS JB750SF3SS JB750SF4SS JB750SJ1SS JB750SJ2SS JB750SJ3SS JB750SJ4SS JB750SJ5SS JB750SJ6SS JB750SJ7SS
 JB750SJ8SS JB750SJ9SS JB755BJ5TS JB755BJ6TS JB755BJ7TS JB755BJ8TS JB755DJ1BB JB755DJ1WW JB755DJ2BB JB755DJ2WW
 JB755DJ3BB JB755DJ3WW JB755EJ1ES JB755EJ2ES JB755EJ3ES JB755EJ4ES JB755EJ5ES JB755EJ6ES JB755EJ7ES JB755EJ8ES
 JB755EJ9ES JB755FJ5DS JB755FJ6DS JB755FJ7DS JB755FJ8DS JB755FJ9DS JB755SJ1SS JB755SJ2SS JB755SJ3SS JB755SJ4SS
 JB755SJ5SS JB755SJ6SS JB755SJ7SS JB755SJ8SS JB755SJ9SS JB850DF1BB JB850DF1WW JB850DF2BB JB850DF2WW
 JB850DF4BB JB850DF4WW JB850EF1ES JB850EF2ES JB850EF4ES JB850SF1SS JB850SF4SS JB860BJ5TS JB860BJ6TS
 JB860BJ7TS JB860BJ8TS JB860BJ9TS JB860BJATS JB860DJ1BB JB860DJ1WW JB860DJ2BB JB860DJ2WW JB860DJ3BB
 JB860DJ3WW JB860DJ4BB JB860DJ4WW JB860DJ5BB JB860DJ5WW JB860DJ6BB JB860DJ6WW JB860DJ7BB JB860DJ7WW
 JB860DJ8BB JB860DJ8WW JB860DJ9BB JB860DJ9WW JB860EJ1ES JB860EJ2ES JB860EJ3ES JB860EJ4ES JB860EJ5ES
 JB860EJ6ES JB860EJ7ES JB860EJ8ES JB860EJ9ES JB860EJAES JB860FJ5DS JB860FJ6DS JB860FJ7DS JB860FJ8DS
 JB860FJ9DS JB860FJADS JB860SJ1SS JB860SJ2SS JB860SJ3SS JB860SJ4SS JB860SJ5SS JB860SJ6SS JB860SJ7SS
 JB860SJ8SS JB860SJ9SS JB860SJASS JB870DF1BB JB870DF2BB JB870DF3BB JB870DF4BB JB870SF1SS JB870SF2SS
 JB870SF4SS JB870TF1WW JB870TF2WW JB870TF3WW JB870TF4WW JBS60DF1BB JBS60DF1WW JBS60DF2BB JBS60DF2WW
 JBS60DF3BB JBS60DF3WW JBS60DF4BB JBS60DF4WW JBS60DK1BB JBS60DK1WW JBS60DK2BB JBS60DK2WW JBS60DK3BB
 JBS60DK3WW JBS60DK4BB JBS60DK4WW JBS60DK5BB JBS60DK5WW JBS60DK6BB JBS60RF1SS JBS60RF2SS JBS60RF3SS
 JBS60RF4SS JBS60RK1SS JBS60RK2SS JBS60RK3SS JBS60RK4SS JBS60RK5SS JBS60RK6SS JBS65DF1BB JBS65DF1WW
 JBS65RF1SS JBS86SP1SS JCB850SF1SS JCB850SF4SS JCB865S1SS JCB865S2SS JCB865S3SS JCB865S4SS JCB865S5SS
 JCB865S6SS JCB865S7SS JCB865S8SS JCB865S9SS JCP336DD1BB JCP336DD1WW JCP336DD2BB JCP336DD2WW
 JCP336SD1SS JCP336SD2SS JCP346BM2BB JCP346BM3BB JCP346SM2SS JCP346SM3SS JCP346WM2WW JCP346WM3WW
 JCS630DF2WW JCS630DF3WW JCS968BK4BB JCS968BK5BB JCS968SK4SS JCS968SK5SS JCS968WK4WW JCS968WK5WW
 JD630DF1BB JD630DF1WW JD630DF2BB JD630DF2WW JD630DF3BB JD630DF3WW JD630DF4BB JD630DF4WW JD630DF5BB
 JD630DF5WW JD630DF6BB JD630DF6WW JD630DF7BB JD630DF7WW JD630DF8BB JD630DF8WW JD630DF9BB JD630DF9WW
 JD630SF1SS JD630SF2SS JD630SF3SS JD630SF4SS JD630SF5SS JD630SF6SS JD630SF7SS JD630SF8SS JD630SF9SS
 JD750DF1BB JD750DF2BB JD750SF1SS JD750SF2SS JD750SF3SS JD968BK4BB JD968BK5BB JD968KK4CC JD968SK5SS
 JD968SK6SS JD968TK4WW JD968TK5WW JP256BM2BB JP256BM3BB JP256WM2WW JP3030DJ1BB JP3030DJ2BB JP3030DJ3BB

COMPATIBLE MODELS CONTINUED:

JP3030DJ4BB JP3030SJ1SS JP3030SJ2SS JP3030SJ3SS JP3030SJ4SS JP3030TJ1WW JP3030TJ2WW JP3030TJ3WW JP3030TJ4WW JP3036DL1BB
 JP3036DL2BB JP3036SL1SS JP3036SL2SS JP3036TL1WW JP3036TL2WW JP336DD1BB JP336DD1WW JP336DD2BB JP336DD2WW JP336SD1SS
 JP336SD2SS JP340BM2BB JP346BM2BB JP346BM3BB JP346CM2CC JP346CM3CC JP346SM2SS JP346SM3SS JP346WM2WW JP346WM3WW
 JP3530DJ1BB JP3530DJ2BB JP3530DJ3BB JP3530DJ4BB JP3530SJ1SS JP3530SJ2SS JP3530SJ3SS JP3530SJ4SS JP3530TJ1WW JP3530TJ2WW
 JP3530TJ3WW JP3530TJ4WW JP3536DJ1BB JP3536DJ2BB JP3536SJ1SS JP3536SJ2SS JP3536TJ1WW JP3536TJ2WW JP356BM2BB JP356BM3BB
 JP356BM4BB JP356SM2SS JP356SM3SS JP356SM4SS JP356WM2WW JP356WM3WW JP356WM4WW JP5030DJ1BB JP5030DJ2BB JP5030SJ1SS
 JP5030SJ2SS JP5036DJ1BB JP5036DJ2BB JP5036SJ1SS JP5036SJ2SS JP655BM2BB JP655SM2SS JP655TM2WW JP656DD1BB JP656DD1WW
 JP656DD2BB JP656DD2BV JP656DD2WW JP656SD1SS JP656SD2SS JS630DF1BB JS630DF1CC JS630DF1WW JS630DF2BB JS630DF2CC
 JS630DF2WW JS630DF3BB JS630DF3CC JS630DF3WW JS630DF4BB JS630DF4CC JS630DF4WW JS630DF5BB JS630DF5CC JS630DF5WW
 JS630SF1SS JS630SF2SS JS630SF3SS JS630SF4SS JS630SF5SS JS645DL2WW JS645DL3WW JS645DL4WW JS645EL1ES JS645EL2ES JS645EL3ES
 JS645EL4ES JS645FL1DS JS645FL2DS JS645FL3DS JS645FL4DS JS645SL1SS JS645SL2SS JS645SL3SS JS645SL4SS JS660EL1ES JS660EL2ES
 JS660EL3ES JS660SL1SS JS660SL2SS JS750DF1BB JS750DF1WW JS750DF2BB JS750DF2WW JS750DF3BB JS750DF3WW JS750DF4BB JS750DF4WW
 JS750EF1ES JS750EF2ES JS750EF3ES JS750EF4ES JS750SF1SS JS750SF2SS JS750SF3SS JS750SF4SS JS760BL1TS JS760BL2TS JS760BL3TS
 JS760BL4TS JS760BL5TS JS760DL1BB JS760DL1WW JS760DL2BB JS760DL2WW JS760DL3BB JS760DL4BB JS760DL4WW JS760DL5BB JS760DP1BB
 JS760DP1WW JS760EL1ES JS760EL2ES JS760EL3ES JS760EL4ES JS760EL5ES JS760EP1ES JS760FL1DS JS760FL2DS JS760FL3DS JS760FL4DS
 JS760FL5DS JS760FP1DS JS760SL1SS JS760SL2SS JS760SL3SS JS760SL4SS JS760SL5SS JS760SP1SS JS968BK4BB JS968BK5BB JS968KK4CC
 JS968KK5CC JS968SK5SS JS968SK6SS JS968TK4WW JS968TK5WW JSS86SP1SS MBC12GAZLSS MBC12GAZW WW PB911BJ5TS PB911BJ6TS
 PB911BJ7TS PB911BJ8TS PB911BJ9TS PB911BJATS PB911DJ1BB PB911DJ2BB PB911DJ3BB PB911DJ4BB PB911EJ1ES PB911EJ2ES PB911EJ3ES
 PB911EJ4ES PB911EJ5ES PB911EJ6ES PB911EJ7ES PB911EJ8ES PB911EJ9ES PB911FJ6DS PB911FJ7DS PB911FJ8DS PB911SJ1SS PB911SJ2SS
 PB911SJ3SS PB911SJ4SS PB911SJ5SS PB911SJ6SS PB911SJ7SS PB911SJ8SS PB911SJASS PB911TJ1WW PB911TJ2WW PB911TJ3WW PB911TJ4WW
 PB930DF1BB PB930DF2BB PB930DH1BB PB930DH2BB PB930DH3BB PB930SF1SS PB930SF2SS PB930SH1SS PB930SH2SS PB930SH3SS
 PB930SJ1SS PB930SJ2SS PB930SJ3SS PB930SJ4SS PB930SL1SS PB930SL2SS PB930SL3SS PB930SL4SS PB930SL5SS PB930TF1WW PB930TF2WW
 PB930TH1WW PB930TH2WW PB930TH3WW PB935BP1TS PB935BP2TS PB935YP1FS PB935YP2FS PB950SF1SS PB950SF2SS PB950SF4SS
 PB955SF1SS PB960BJ4TS PB960BJ5TS PB960BJ6TS PB960BJ8TS PB960BJ9TS PB960DJ1BB PB960DJ2BB PB960DJ3BB PB960EJ1ES PB960EJ2ES
 PB960EJ3ES PB960EJ4ES PB960EJ5ES PB960EJ6ES PB960EJ7ES PB960FJ4DS PB960FJ5DS PB960FJ6DS PB960FJ7DS PB960FJ8DS PB960SJ1SS
 PB960SJ2SS PB960SJ3SS PB960SJ4SS PB960SJ5SS PB960SJ6SS PB960SJ9SS PB960TJ1WW PB960TJ2WW PB960TJ3WW PB980SJ1SS
 PB980SJ2SS PB980SJ3SS PB980SJ4SS PB980SJ5SS PB980SJ6SS PB980SJ8SS PCB950SF1SS PCB950SF2SS PCB950SF4SS PCB980SJ1SS
 PCB980SJ2SS PCB980SJ3SS PCB980SJ4SS PCB980SJ5SS PCB980SJ7SS PCB980SJ8SS PCP912BM2BB PCP912BM3BB PCP912SM2SS PCP912SM3SS
 PCP912TM2WW PCP912TM3WW PCP932BM2BB PCP932BM3BB PCP932BM4BB PCP932SM2SS PCP932SM3SS PCP932SM4SS PCP932TM2WW
 PCP932TM3WW PCP932TM4WW PCS968DP1BB PCS968DP1WW PCS968DP2BB PCS968DP2WW PCS968SP1SS PCS968SP2SS PD968DP1BB
 PD968DP2BB PD968DP3BB PD968SP1SS PD968SP2SS PD968SP3SS PD968TP1WW PD968TP2WW PD968TP3WW PP7030BM1TS PP7030DJ1BB
 PP7030DJ2BB PP7030EJ1ES PP7030SJ1SS PP7030SJ2SS PP7036BM1TS PP7036DJ1BB PP7036DJ2BB PP7036EJ1ES PP7036SJ1SS PP7036SJ2SS
 PP9030DJ1BB PP9030DJ2BB PP9030SJ1SS PP9030SJ2SS PP9036DJ1BB PP9036DJ2BB PP9036SJ1SS PP9036SJ2SS PP912BM2BB PP912BM3BB
 PP912BM4BB PP912KM2CC PP912KM3CC PP912KM4CC PP912SM2SS PP912SM3SS PP912SM4SS PP912TM2WW PP912TM3WW PP912TM4WW
 PP932BM2BB PP932BM3BB PP932BM4BB PP932EH1ES PP932KM2CC PP932SM2SS PP932SM3SS PP932SM4SS PP932TM2WW PP942BM2BB
 PP942BM3BB PP942SM2SS PP942SM3SS PP942TM2WW PP942TM3WW PP944DT1BB PP944DT2BB PP944ST1SS PP944ST2SS PP944TT1WW
 PP944TT2WW PP945BM2BB PP945BM3BB PP945SM2SS PP945SM3SS PP945WM2WW PP945WM3WW PP972BM2BB PP972BM3BB PP972KM2CC
 PP972KM3CC PP972SM2SS PP972SM3SS PP972TM2WW PP975BM2BB PP975BM3BB PP975SM2SS PP975SM3SS PP975WM2WW PP975WM3WW
 PS920SF1SS PS920SF2SS PS920SF3SS PS950EF1ES PS950EF3ES PS950SF1SS PS950SF2SS PS950SF3SS PS960BL1TS PS960BL2TS PS960BL3TS
 PS960BL4TS PS960BL5TS PS960EL1ES PS960EL2ES PS960EL3ES PS960EL4ES PS960FL1DS PS960FL2DS PS960FL3DS PS960FL4DS PS960SL1SS
 PS960SL2SS PS960SL3SS PS960SL4SS PS960SL5SS PS960YP1FS PS968DP1BB PS968DP2BB PS968DP3BB PS968SP1SS PS968SP2SS PS968SP3SS
 PS968TP1CC PS968TP1WW PS968TP2CC PS968TP2WW PS968TP3CC PS968TP3WW QAS740RM2SS XB625DK4WW XB625DK5BB XB625DK5WW
 XB625RK4SS XB625RK5SS ZEU30RSJ1SS ZEU30RSJ2SS ZEU30RSJ3SS ZEU36KBK2BB ZEU36KSK2SS ZEU36KSK3SS ZEU36KWK2WW ZEU36RSJ1SS
 ZEU36RSJ2SS ZEU36RSJ3SS CS975SD1SS CS980SN1SS CS980SN2SS CS980SN3SS CS980ST1SS CS980ST2SS CS980ST3SS QSS740BN1TS
 QSS740RN1SS

ALTERNATE PART NUMBERS:

AP4484422, 1556232, AH2370248,
EA2370248, PS2370248

