



# INSTALLATION INSTRUCTIONS AND SAFETY PRECAUTIONS

FOR YOUR SAFETY, READ INSTRUCTIONS COMPLETELY AND CAREFULLY.

## WARNING - POTENTIAL FIRE AND SHOCK HAZARD

IF YOU ARE NOT FAMILIAR WITH ELECTRICAL INSTALLATION, SEEK A QUALIFIED SERVICE PROFESSIONAL.



### CONTENTS:

- APPLIANCE POWER CORD
- STRAIN RELIEF COLLAR AND SCREWS

### SAFETY PRECAUTIONS

- SUPPLYING DEMAND ASSUMES NO RESPONSIBILITIES FOR INSTALLATION OF APPLIANCE CORD.
- DO NOT USE AN EXTENSION CORD.
- DO NOT USE IF CORD IS DAMAGED, CUT, WORN, OR FRAYED.
- DO NOT EXCEED ELECTRICAL RATINGS.
- IF YOUR APPLIANCE HAS A MANUAL TIMER AND IS NOT IN THE OFF POSITION, ENSURE THE APPLIANCE IS IN AN OFF STATE BEFORE INTRODUCING POWER.
- OBSERVE ALL GOVERNING CODES AND ORDINANCES.
- PROPER INSTALLATION IS THE RESPONSIBILITY OF THE INSTALLER.

**BEFORE MAKING THE ELECTRICAL CONNECTION, TURN OFF THE CIRCUIT BREAKER(S) OR REMOVE THE APPLIANCE'S CIRCUIT FUSE(S) AT THE ELECTRICAL BOX. BE SURE THE POWER CORD IS UNPLUGGED FROM THE WALL.**

**NEVER LEAVE THE ACCESS COVER OFF THE TERMINAL BLOCK.**

- PRODUCT FAILURE DUE TO IMPROPER INSTALLATION IS NOT COVERED UNDER THE WARRANTY.
- IMPROPER INSTALLATION OR WIRING ERRORS CAN CAUSE DAMAGE TO THE APPLIANCE, RESULT IN FIRE, OR CAUSE FATAL SHOCK.
- ALWAYS INSTALL STRAIN RELIEF.
- AFTER CORD IS PROPERLY INSTALLED, IT'S A BEST PRACTICE TO CHECK CONTINUITY OF GROUNDING CONNECTION BETWEEN THE METAL FRAME OF THE APPLIANCE AND THE CENTER PIN ON THE CORD WITH A MULTI-METER TO ENSURE THE APPLIANCE IS PROPERLY GROUNDED.

QUESTIONS? [HELP@SUPPLYINGDEMAND.COM](mailto:HELP@SUPPLYINGDEMAND.COM)



# **INSTALLATION INSTRUCTIONS**

- 1. ENSURE YOUR CORD MATCHES THE APPLIANCE'S SPECIFICATIONS AND MEETS ALL APPLICABLE BUILDING AND/OR ELECTRICAL STANDARDS AND CODES.**
- 2. LOCATE TERMINAL BLOCK ACCESS COVER AND POWER CORD ENTRY KNOCKOUT ON APPLIANCE, IF EQUIPPED.**
- 3. INSTALL STRAIN RELIEF, IF INCLUDED, BY INSERTING EARS INTO KNOCKOUT HOLE AND USING SCREWS TO CONNECT TOP AND BOTTOM.**
- 4. INSERT POWER CORD LEADS THROUGH STRAIN RELIEF OPENING.**
- 5. SECURELY ATTACH POWER CORD TO TERMINAL BLOCK. ENSURE THE CABLE IS PROPERLY AND SECURELY ATTACHED. LOOSE CONNECTIONS CAN RESULT IN SHORT, FIRE, OR ELECTRICAL SHOCK.**
- 6. PUSH A FEW INCHES OF CORD THROUGH STRAIN RELIEF AND TIGHTEN.**
- 7. REINSTALL TERMINAL BLOCK COVER.**